

BioZone AirCare Lamp Replacement



Maintenance

AirCare does not require much maintenance. If the device is in a very smoky or dusty environment, we suggest you open the device and clean the UV lamp with some alcohol (every 3 months). If you do not clean the lamp, the cleaning effect is gradually reduced. If the device is placed in a garbage room, it may be good to clean inside and outside the unit once a month. It may also be good to cover the sides with a piece of cloth if there are a lot of flies and / or dust.

Replacing the lamp

After approximately 1 year of continuous operation (2 years if the device is used occasionally) the power of the UV lamp decreases and it needs to be replaced. Press down the key and turn it counterclockwise $\frac{1}{4}$ lap, to turn off the unit (off) and unlock (open) the cover. Remove the key and gently bolt with a screwdriver or the end of the key between the bottom plate and the cover.

Remove the cover. All electronics are located on the bottom plate.

Replace lamp (use only BioZone original lamp, use of other lamp will cancel warranty)

Replace the cover (important to get it right - read inside the cover), plug in and start the device, by pressing down the key and turn it clockwise $\frac{1}{4}$ lap .

Check that the UV light is on (blue shine)?

Note! Environmentally hazardous waste! The lamp is thrown in containers intended for lamps containing mercury.

Lamp

AC-D 10	lampa nr 10-08025
AC-D 20	lampa nr 10-08050
AC-D 30	lampa nr 10-08100

Specifications

Size	49 x 17,5 x 12 cm
Weight	approx. 2,2 kg
Cord length	2,5 m
Power consumption	< 20W
Ozone output	Accumulation will not exceed 0.04 ppm, if the device is used according to instructions.
Ion Generation	Photo ionization of negative ions.
Material	ABS, Aluminium Composite.
Electrical input	12 V DC
Temperatures between	-20 degrees Celcius to + 40 degrees Celsius.
Manufacturing	Made in China, EPA-approved factory.
Warranty	1 year

Warranty

Warranty

The BioZone devices are manufactured and tested according to the latest methods. The carefully selected components and fabrication materials ensure you a carefree use. We grant one (1) year product warranty on both the device and the lamp calculated from the date of purchase. The purchase receipt or invoice is valid as a guarantee certificate.

The warranty does not apply if the appliance has become neglected, for example been dropped at the floor, has been exposed to water or if you have not used original lamps or original power sources. The warranty does not apply unless the device is used in accordance with the instructions.

The warranty does not apply to damage caused by lightning strikes.

*If you have any problems, contact us at , +351 92 422 98 45
or via the website www.biozone.one.*

Before you may return your **BioZone**, we would like you to investigate the following:

The fan works but the lamp is not lit:

Check that the lamp is securely placed in its holder by opening the cover.

Check that the cover is securely closed.

The device is equipped with a defense against overheating. It may have been activated.

Disconnect the device and wait 30 minutes before attempting again.

The lamp may be broken. Replace with a new one. Contact Us!

Neither the fan nor the lamp works:

Verify that the device is properly connected to electricity.

Make sure there is no fault in the power outage.

If none of the above works please contact us before returning, so that we can help you!